westomatic make it happen

Antovista



WEEKLY CLEANING AND FILLING GUIDE



NB: THIS MACHINE MUST BE CLEANED DAILY

HYGIENE KIT

CLEANING PARTS

ALL MACHINES WILL BE SUPPLIED WITH A FULL HYGIENE & CARE KIT AS STANDARD.


WE RECOMMEND THAT YOU SWAP THE PARTS OUT, AND TAKE AWAY TO WASH, ENSURING THE PARTS ARE PROPERLY CLEANED AND MINIMISING MACHINE DOWNTIME.





AUTORISTA HYGIENE KIT






IN ADDITION TO THE DAILY CLEANING, EACH WEEK THE MACHINE MUST HAVE A
DEEPER CLEAN TO ENSURE PROPER HYGIENE & FUNCTIONALITY OF THE MACHINE

1 REMOVE NOZZLES AND CLEAN THE NOZZLE PLATE





- UNSCREW THE WASHERS ON THE PLATE AND REMOVE THE NOZZLE PLATE
- REMOVE ALL THE PLATE. NOZZLES. PIPES AND THE CENTRAL NOZZLE HOLDER
- WASH THOROUGHLY IN WARM SOAPY WATER & REASSEMBLE CORRECTLY USING THE PIPE GUIDELINE LOCATED ON THE RIGHT WALL OF THE MACHINE

















2 REMOVE AND CLEAN THE TEA BREWER











YOU MAY NEED TO LOOSEN THE BOLT AT THE BACK



SLIDE THE LEVER TO THE LEFT



PULL THE FILTER
PLATFORM FORWARDS



REMOVE THE BREWING CHAMBER & CLEAN




EVERY 5000 VENDS
REPLACE FILTER BELT

REASSEMBLE ALL PARTS, ENSURING SOLENOID IS HELD IN PLACE WITH THE BOLT AT THE BACK, AND THE PIPE IS CLIPPED BACK INTO PLACE

EXTENDED BREWER CLEAN

THIS TYPE OF CLEAN UTILISES A CLEANING TABLET TO REMOVE THE OILS LEFT IN THE BREWER AND HELPS TO KEEP THE DRINKS TASTING FRESH.





After you have cleaned the brewer parts, drop a Westomatic brewer cleaning tablet into the brewer chamber and perform a clean.

To do this use the menu = icon, enter the component menu, and then brewers.

Select the KUBE brewer and press FLUSH or EXTENDED FLUSH.

The brewer will then perform a cleaning cycle flushing the tablet through.

EVERY 6 MONTHS

YOUR SERVICE TECHNICIAN WILL NEED TO DO THE FOLLOWING EVERY 6 MONTHS:

BOILER:

- · De-scale, and clean.
- Replace Boiler valves

WATER:

- Replace Filters & Calibrate
- · Check for leaks & check temperature

WHIPPER DECK:

- Clean Extraction
- · Check all whipper motors
- Replace Hygiene parts, seals & O Rings

BREWER

- Remove and clean Fit Service Kit
- Check Calibration
- Replace Grinder Blades if needed (30000 vends)
- Perform Cleaning Cycle

CUP SENSOR:

• Re-calibrate

MOVING DISPENSE HEAD:

Check position - nozzles should align with cup dispense area

User Guide

4 SIMPLE STEPS

PLACE CUP
IN DISPENSE AREA

2

TOUCH SCREEN, SELECT A DRINK, CHOOSE YOUR OPTIONS

3

ALLOW MACHINE TO DISPENSE DRINK

4

REMOVE CUP & ENJOY



CONTACT



Units 7-8 Block 4 Forde Court, Forde Road, Brunel Industrial Estate, Newton Abbot, Devon, TO12 4BT

www.westomatic.com

westomatic make it happen



+44 (0)1626 323100



support@westomatic.com



www.westomatic.com