



SHMOO

6 MONTH CHECK UP





SHMOO

westomatic

6 month Check up!

Key areas to look at:

STERILISE

- Water Lines
- All contact & hygiene parts

REPLACE

- UV Filter
- Water Filters (Microplastics/Sediment)

CLEAN

- Bottle Dispense Area
 - Floor
 - Door
 - Waste bucket
- Using a microfibre cloth & sanitising spray:
- Hover Select Buttons
 - Digital Screen

TEST

- Test all drinks
- Adjust levels if necessary

CLEAN!

Safety Checks:

- **PAT test machine** - Insulation & Earth Bond only
- **Check Mains Lead** - for damage/do not connect to extension lead
- **Check Fuses** -correct value and type
- **Check Looms** - connections are free from damage and fully secured



Tools Required

- PAT Tester
- Vending Hydrogen peroxide sanitiser
- Soft Microfibre cloths
- Sanitising Spray
- Cleaning Cloths
- Bucket of warm sanitising water
- Scale / Jug / Cup for testing

Estimated Labour Time - 0.75hrs

PARTS LIST



Shmoo Hygiene Kit

PN: 2100039



Nozzle - Spout Dispense Tube

PN: 1044002



UV Filter Kit

PN: 2100047



Tubing - 8mm x 2mm

PN: 1029012



Water Filter Microplastics

PN: 1024023



Water Filter Sediment

PN: 1024024



Canister - Small

PN: 1012003



Canister - Large

PN: 1012044